

Fingerprint Modeling + Orientation Field Estimation

Prof. Arun Ross

Michigan State University

rossarun@cse.msu.edu

<http://iprobe.cse.msu.edu>

Thanks to:

Dr. Jianjiang Feng

Tsinghua University




Fingerprint Modeling


Ridge pattern in a local area of a fingerprint can be approximated by a **cosine wave**

$$w(x, y) = A \cos(2\pi f(x \cos \theta + y \sin \theta))$$

pixel value amplitude frequency orientation



Local fingerprint region




Shown as surface

Fingerprint Model


- $w(x, y) = A \cos(2\pi f(x \cos \theta + y \sin \theta))$
- The **local fingerprint** region can be modeled using this equation
- Consider:
 - A **300 x 300** blank image (as an example)
 - Some values for parameters f, θ, A
- By varying (x, y) in the range 1:300, the pixel intensity at (x, y) can be computed

Fingerprint Model


Examples




$$A = 50; f = 10; \theta = \pi/4;$$



$$A = 80; f = 0.01; \theta = \pi/4;$$



$$A = 50; f = 0.1; \theta = \pi;$$



$$A = 50; f = 0.01; \theta = \pi/2;$$

2 methods to compute orientation field

- The first one is based on the **Fourier Transform** applied to the local region
- The second one is based on **filtering the image** using edge detection filters


Ridge orientation & frequency estimation

2D Fourier transform of cosine wave


$$W(u, v) = \frac{A}{2} [\delta(u - f \cos \theta, v - f \sin \theta) + \delta(u + f \cos \theta, v + f \sin \theta)]$$

Let (\hat{u}, \hat{v}) denote the location of the maximum magnitude, then

$$\hat{\theta} = \arctan\left(\frac{\hat{v}}{\hat{u}}\right), \hat{f} = \sqrt{\hat{u}^2 + \hat{v}^2}$$



Magnitude spectrum



Magnitude spectrum shown as surface

Orientation field smoothing


- **Orientation field** computed using the above method is vulnerable to noise.
- Orientation field is particularly important for extracting minutiae. To deal with noise, we should smooth the orientation field.
- Special consideration on ridge orientation:
 - defined in the range $[0, \pi)$
 - θ and $(\theta + \pi)$ are the same orientation
 - the average value between θ and $(\theta + \pi)$ should be θ rather than $\frac{2\theta + \pi}{2}$

Orientation field smoothing


3 steps to smooth orientation field:

- Construct a vector field $V = (V_x, V_y) = (\cos 2\theta, \sin 2\theta)$;
- Perform low pass filtering on the two components of the vector field separately to obtain the smoothed vector field $V' = (V_x', V_y')$;
- Smoothed orientation field is given by $\frac{1}{2} \arctan\left(\frac{V_y'}{V_x'}\right)$.


Orientation field smoothing




Initial OF, θ




$V_x = \cos(2\theta)$




$V_y = \sin(2\theta)$



Smoothed OF, θ'



V_x'



V_y'

Edge Detection

- Image filters can be used to detect edges in an image
- An edge corresponds to a collection of pixels
- The pixel intensity changes sharply across the edge
 - An edge may correspond to the boundary of an object
 - In the case of fingerprints, the contours of the ridges may be viewed as “boundaries”
- The magnitude of the gradient or difference in pixel intensities in the neighborhood of a pixel can help in detecting edge pixels

Edge Filters (Kernels)

- Gradient can be computed in the **horizontal** and **vertical** directions
- **Prewitt Filters:**

$$P_x = \begin{bmatrix} -1 & -1 & -1 \\ 0 & 0 & 0 \\ +1 & +1 & +1 \end{bmatrix} \quad \leftarrow \text{This will highlight horizontal edges}$$

$$P_y = \begin{bmatrix} -1 & 0 & +1 \\ -1 & 0 & +1 \\ -1 & 0 & +1 \end{bmatrix} \quad \leftarrow \text{This will highlight vertical edges}$$

Edge Filters (Kernels)


- Gradient can be computed in the **horizontal** and **vertical** directions
- **Sobel Filters:**

$$S_x = \begin{bmatrix} -1 & -2 & -1 \\ 0 & 0 & 0 \\ +1 & +2 & +1 \end{bmatrix} \quad \leftarrow \text{This will highlight horizontal edges}$$

$$S_y = \begin{bmatrix} -1 & 0 & +1 \\ -2 & 0 & +2 \\ -1 & 0 & +1 \end{bmatrix} \quad \leftarrow \text{This will highlight vertical edges}$$

Convolution: Gradient Images

- The image, I , is **convolved** with the edge filters to obtain two gradient images, G_x and G_y
 - $G_x = I \otimes S_x$
 - $G_y = I \otimes S_y$



Convolution: Gradient Images

- The image, I , is **convolved** with the edge filters to obtain two gradient images, G_x and G_y
 - $G_x = I \otimes S_x$
 - $G_y = I \otimes S_y$
- **Magnitude** of Gradient at a pixel (a,b) is $[G_x(a,b)]^2 + [G_y(a,b)]^2$
- **Edge direction** at the pixel can also be computed

Computing Orientation Field

- $O(x,y) =$

$$\frac{1}{2} \tan^{-1} \left[\frac{\sum_{i=-k}^k \sum_{j=-k}^k 2G_x(x+i,y+j)G_y(x+i,y+j)}{\sum_{i=-k}^k \sum_{j=-k}^k G_x^2(x+i,y+j) - G_y^2(x+i,y+j)} \right]$$

- So first apply the **two filters** independently on the image
- Based on the two filtered outputs, compute the **orientation** at a pixel

Singularity extraction

Let $O[i], i = 0, \dots, 7$, denote the orientations at 8 neighbors of point x .

| | | |
|---|-----|---|
| 3 | 2 | 1 |
| 4 | x | 0 |
| 5 | 6 | 7 |

Poincaré index (PI) at x is:

$$PI = \frac{1}{\pi} \sum_{i=0}^7 \delta(O[(i+1)_{\text{mod } 8}] - O[i]),$$


where

$$\delta(\theta) = \begin{cases} \theta - \pi, & \text{if } \theta > \pi/2 \\ \theta, & \text{if } -\pi/2 \leq \theta \leq \pi/2 \\ \theta + \pi, & \text{if } \theta < -\pi/2 \end{cases}$$

This function is used to make sure the orientation change is within ± 90 degrees

Note that above equations assume “radians”.


Poincaré index in fingerprint



| | | |
|----|----|----|
| 5 | 10 | -5 |
| 7 | | 13 |
| 10 | 8 | -1 |

Non-singularity


0



| | | |
|----|----|-----|
| 45 | 0 | -45 |
| 65 | | -65 |
| 80 | 90 | -80 |

Loop


1



| | | |
|----|----|-----|
| 65 | 90 | -65 |
| 45 | | -45 |
| 10 | 0 | -10 |

Delta

-1



| | | |
|-----|---|-----|
| 45 | 0 | -45 |
| 90 | | 90 |
| -45 | 0 | 45 |

Whorl


2

Here, angle is specified in “degrees”. In some cases, it will be specified in “radians”

Pattern classification


We can classify a fingerprint into one of 6 major pattern types based on singular points (SP):

- **plain arch**: contains no SP.
- **left loop**: contains 1 delta and 1 loop whose direction points to the left side of the delta.
- **right loop**: contains 1 delta and 1 loop whose direction points to the right side of the delta.



Pattern classification

- **tented arch**: contains 1 delta and 1 loop whose direction points toward the delta.
- **whorl**: contains at least 2 loops and 2 deltas where ridge orientation field around the two loops form a circular orbit.
- **twin loop**: contains at least 2 loops and 2 deltas where the ridge orientation field around the two loops do not form a circular orbit.



Ridge extraction


- A straightforward method is **binarization**.
- Problems:
 - Sweat pores on ridges are brighter than the surrounding pixels;
 - ridges can be broken due to cuts or creases;
 - adjacent ridges may appear to be joined due to wet skin or large pressure.
- Countermeasure: fingerprint **enhancement**.
- General purpose image enhancement is not effective for fingerprint.
- A successful fingerprint enhancement method is **contextual filtering**, such as Gabor filtering.

2D Gabor filters

2D Gabor wavelet:


$$G(x, y) = e^{-\pi[(x-x_0)^2/\alpha^2 + (y-y_0)^2/\beta^2]} e^{-2\pi i[u_0(x-x_0) + v_0(y-y_0)]}$$

where (x_0, y_0) denote the position in the image, (α, β) denote the effective width and length, and (u_0, v_0) denote the wave direction with a spatial frequency $\omega_0 = \sqrt{u_0^2 + v_0^2}$.



Real parts of Gabor filters (8 orientations and 3 scales)

Effect of Gabor filtering





Ridge extraction

- Enhanced image can be converted into a binary image by comparing with **thresholds** (e.g. local mean).
- A morphological operation, **thinning**, is used to obtain the skeleton image.
- Thinning is a common technique in image processing, which involves iteratively removing outer ridge pixels.




Minutiae extraction

- Minutiae are special points on ridges:
 - ridge bifurcation (3 neighbors are black)
 - ridge ending (1 neighbor is black)
- Direction of a ridge ending:
 - Trace the associated ridge with a fixed distance (say 10 pixels) from x to a . The direction xa is the minutia direction.
- Direction of a bifurcation:
 - Trace the ridges to get three directions. The direction is the mean of the two smallest different directions.



Minutiae verification

- Previous method considers only 3×3 window, producing false minutiae due to:
 - artifacts in image processing
 - noise in a fingerprint
- A minutia is classified as false if it meets any of the following conditions:
 - has no adjacent ridge on either side
 - be close in location and opposite in direction
 - too many minutiae in a small neighborhood



Handbook of fingerprint recognition

